

# [POWER COMMANDER V]

## **2013 Arctic Cat 700cc H1 ATV**

### **Installation Instructions**



#### **PARTS LIST**

- 1 Power Commander
- 1 USB Cable
- 1 Installation Guide
- 2 Power Commander Decals
- 2 Dynojet Decals
- 1 Posi-tap
- 2 Velcro strips
- 1 Alcohol swab

**THE IGNITION MUST BE TURNED  
OFF BEFORE INSTALLATION!**


THE LATEST POWER COMMANDER  
SOFTWARE AND MAP FILES CAN BE  
DOWNLOADED FROM OUR WEB SITE AT:  
[www.powercommander.com](http://www.powercommander.com)

**PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION**

**Dynojet**

2191 Mendenhall Drive North Las Vegas, NV 89081 (800) 992-4993 [www.powercommander.com](http://www.powercommander.com)

# POWER COMMANDER V INPUT ACCESSORY GUIDE



Optional Accessories such as  
POD-300 unit or Auto-tune kit

## Wire connections:

To input wires into the PCV first remove the rubber plug on the backside of the unit and loosen the screw for the corresponding input. Using a 22-24 gauge wire strip about 10mm from its end. Push the wire into the hole of the PCV until it stops and then tighten the screw. Make sure to reinstall the rubber plug.

NOTE: If you tin the wires with solder it will make inserting them easier.



## ACCESSORY INPUTS

### Map -

(Input 1 or 2) The PCV has the ability to hold 2 different base maps. You can switch on the fly between these two base maps when you hook up a switch to the MAP inputs. You can use any open/close type switch. The polarity of the wires is not important. When using the Autotune kit one position will hold a base map and the other position will let you activate the learning mode. When the switch is "CLOSED" Autotune will be activated. (Set to Switch Input #1 by default.)

### Shifter-

(Input 1 or 2) These inputs are for use with the Dynojet quickshifter. Insert the wires from the Dynojet quickshifter into the SHIFTER inputs. The polarity of the wires is not important. (Set to Switch Input #2 by default.)

### Speed-

If your application has a speed sensor then you can tap into the signal side of the sensor and run a wire into this input. This will allow you to calculate gear position in the Control Center Software. Once gear position is setup you can alter your map based on gear position and setup gear dependent kill times when using a quickshifter.

### Analog-

This input is for a 0-5v signal such as engine temp, boost, etc. Once this input is established you can alter your fuel curve based on this input in the control center software.

### Crank-


Do **NOT** connect anything to this port unless instructed to do so by Dynojet. It is used to transfer crank trigger data from one module to another.



- 1 Remove the seat and left hand side panel shown in Figure A.




- 2 Remove the storage cover shown in Figure B and the storage bin.



- 3 Loosen the clamp from the throttle body and remove the air snorkel from the throttle body.
- 4 To make the fuel injector more accessible, lift the snorkel/airbox upward away from the top of the engine.
- 5 Remove the two screws securing the tool kit to expose the battery.
- 6 Using the supplied Velcro, secure the PCV under the seat at the location shown in Figure C.  
*Clean both surfaces with the supplied alcohol swab before attaching the Velcro.*
- 7 Route the PCV wiring harness under the frame spar toward the front of the machine.
- 8 Attach the ground wire from the PCV to the negative (-) terminal of the battery.




**FIG.D**



- 9 Disconnect the stock wiring harness from the fuel injector (Fig. D).
- 10 Plug the PCV wiring harness in-line of the fuel injector and the stock wiring harness.

**FIG.E**



- 11 Locate the Throttle Position Sensor (TPS) on the left hand side of the throttle body.
- 12 Using the supplied posi-tap, attach the GREY wire from the PCV to the stock GREEN/BLACK wire from the TPS.
- 13 Replace the storage bin, cover, tool kit, side panel, and seat.

