

# [POWER COMMANDER V]

**2008-2012 Kawasaki EX250**

(Fuel Injected Models Only)

## Installation Instructions



### PARTS LIST

- 1 Power Commander
- 1 USB Cable
- 1 Installation Guide
- 2 Power Commander Decals
- 2 Dynojet Decals
- 2 Velcro strips
- 1 Alcohol swab
- 1 O2 Optimizer

**THE IGNITION MUST BE TURNED  
OFF BEFORE INSTALLATION!**


THE LATEST POWER COMMANDER  
SOFTWARE AND MAP FILES CAN BE  
DOWNLOADED FROM OUR WEB SITE AT:  
[www.powercommander.com](http://www.powercommander.com)

**PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION**

**Dynojet**

2191 Mendenhall Drive North Las Vegas, NV 89081 (800) 992-4993 [www.powercommander.com](http://www.powercommander.com)

# POWER COMMANDER V INPUT ACCESSORY GUIDE



## Wire connections:

To input wires into the PCV first remove the rubber plug on the backside of the unit and loosen the screw for the corresponding input. Using a 22-24 gauge wire strip about 10mm from its end. Push the wire into the hole of the PCV until it stops and then tighten the screw. Make sure to reinstall the rubber plug.

NOTE: If you tin the wires with solder it will make inserting them easier.



## ACCESSORY INPUTS

### Map -

(Input 1 or 2) The PCV has the ability to hold 2 different base maps. You can switch on the fly between these two base maps when you hook up a switch to the MAP inputs. You can use any open/close type switch. The polarity of the wires is not important. When using the Autotune kit one position will hold a base map and the other position will let you activate the learning mode. When the switch is "CLOSED" Autotune will be activated. (Set to Switch Input #1 by default.)

### Shifter-

(Input 1 or 2) These inputs are for use with the Dynojet quickshifter. Insert the wires from the Dynojet quickshifter into the SHIFTER inputs. The polarity of the wires is not important. (Set to Switch Input #2 by default.)

### Speed-




If your application has a speed sensor then you can tap into the signal side of the sensor and run a wire into this input. This will allow you to calculate gear position in the Control Center Software. Once gear position is setup you can alter your map based on gear position and setup gear dependent kill times when using a quickshifter.

### Analog-


This input is for a 0-5v signal such as engine temp, boost, etc. Once this input is established you can alter your fuel curve based on this input in the control center software.

### Crank-


Do **NOT** connect anything to this port unless instructed to do so by Dynojet. It is used to transfer crank trigger data from one module to another.



- 1 Remove the seats.
- 2 Remove the fuel tank.
- 3 Lay the PCV in the tail section and route the harness towards the front of the bike. Route the PCV harness down the right side of the bike (Fig. A).
- 4 Move the junction box out of the way and remove the bolt for the battery cover (Fig. A).
- 5 Attach the ground wire of the PCV to the negative side of the battery (Fig. B).
- 6 Reinstall the battery cover and junction box.
- 7 Unplug the stock wiring harness from each injector (Fig. C).





- 8 Plug the PCV harness in-line of the stock wiring harness and injectors (Fig. D).
- ORANGE - cylinder #1  
YELLOW - cylinder #2



- 9 Locate the Primary Throttle Position Sensor on the right hand side of the throttle bodies (Fig. E). This is the GREY 3-pin connector.
- This picture was taken with the coolant bottle moved out of the way*
- 10 Plug the connectors from the PCV in-line of the Primary TPS and the stock wiring harness.
- Make sure you do NOT plug the PCV in-line of the BLACK 3-pin connector and the bike's Secondary TPS.*



- 11 Using the supplied velcro, secure the PCV unit in the tail section (Fig. F).
- Clean the surface area with the supplied alcohol swab prior to applying the Velcro adhesive.*



- 12 Remove the right hand fairing.
- 13 Locate the stock O2 sensor connection. Unplug the O2 sensor from the wiring harness (Fig. G).

- 14 Plug the Dynojet O2 Optimizer into the stock wiring harness.

*The stock O2 sensor will not be connected to anything at this time. It can be removed from the exhaust if desired.*

- 15 Reinstall the fuel tank, bodywork, and seats.

**Optional inputs:**

**Speed** - GREEN/RED wire (pin #5) of the larger ECU connector

**Engine Temperature** - ORANGE wire (pin #17) of the larger ECU connector