

POWER COMMANDER FC

2010-2013 Kawasaki Z1000

Installation Instructions



Parts List

- 1 Power Commander FC
- 1 USB Cable
- 1 Installation Guide
- 2 Dynojet Decals
- 2 Velcro
- 1 Alcohol swab


**THE IGNITION MUST BE TURNED
OFF BEFORE INSTALLATION!**

YOU CAN ALSO DOWNLOAD THE PCFC
CONTROL CENTER SOFTWARE AND
LATEST MAPS FROM OUR WEB SITE AT:
www.powercommander.com

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION

Dynojet

2191 Mendenhall Drive North Las Vegas, NV 89081 (800) 992-4993 www.powercommander.com



Position	Note
Position 1	2010-2013 Kawasaki Z1000 Stock exhaust Stock or aftermarket air filter

SELECTING THE MAP POSITION

The Dynojet Power Commander Fuel Controller (PCFC) comes loaded with up to ten maps. Using a #1 Phillips screwdriver, turn the map select dial to toggle between the loaded maps. Refer to the map position table for the maps included in your PCFC.

USING THE RPM RANGE DIALS

The Low, Mid, and High RPM Dials refer to the RPM range, in thirds, of your vehicle. Each dial allows +/- 10% fuel adjustment on top of what fuel changes are done in the map. With the dial facing straight up, there is no additional fuel change.

For example, if your vehicle revs to 6000 RPM:

- The low RPM dial will adjust 0-2000 RPM
- The mid RPM dial will adjust 2001-4000 RPM
- The high RPM dial will adjust 4001-6000 RPM

USING PCFC CONTROL CENTER

Take your tuning to the next level with the PCFC Control Center software.

- 1 Using your web browser, navigate to www.powercommander.com.
- 2 Click Enter Race Ready.
- 3 Click Downloads.
- 4 Click Access Downloads for Power Commander FC.
- 5 Click the PCFC software Download button.
- 6 Open the zip folder.
- 7 Double-click the install file and follow the on-screen instructions to install the PCFC Control Center software. The PCFC Control Center software and maps will be stored in C:\Program Files\PCFC Control Center.
- 8 Return to the Downloads or Home page where you can enter the make, model, and year of your bike to check for and download additional maps.

LOADING ADDITIONAL MAPS

- 1 Connect the USB cable from the computer to the PCFC. Verify the cable is fully seated in the PCFC.
- 2 Run the Control Center software by double-clicking the program icon installed on your desktop or on your start menu.
- 3 Click Open Map File and select a map file.
- 4 Click Send Map. You can send the map to any of the ten map positions.

ALTERING MAPS USING SOFTWARE

The values in the map represent a percentage of fuel change over stock. A value of 10 in the map indicates at that throttle position and RPM range the vehicle will be 10% richer than stock. If the value is -10, then it would be 10% leaner than stock. You have the ability to fine tune your fuel curve by altering these values. The Control Center software allows a value of +250 to -100 in each cell.



- 1 Remove the main seat and the passenger seat.
- 2 Remove the fuel tank.
- 3 Using the supplied velcro, secure the PCFC to the inner rear fender under the main seat as shown in Figure A.


Make sure to clean both surfaces with the alcohol swab before attaching.

Note: For bikes with a charcoal canister, the PCFC will sit on top of the canister.

- 4 Route the harness towards the front of the bike along the left hand frame tube.



- 5 Slide the bracket at the rear of the air box upwards.
This allows access to the injectors.



- 6 Unplug the stock wiring harness from each of the four injectors.




- 7 Attach the connectors from the PCFC wiring harness to the stock harness and the injectors as shown in Figure D.

The orange wire connects to cylinder #1 (left).

The yellow wire connects to cylinder #2.

The green wire connects to cylinder #3.

The blue wire connects to cylinder #4 (right).



- 8 Attach the ground wire from the PCFC harness to the common stock ground wire location as shown in Figure E.



- 9 Locate the throttle position sensor (TPS) on the right hand side of the bike.

The TPS is behind the coolant hose as shown in Figure F and is the black connector, not the grey connector.

- 10 Unplug the TPS wiring harness.

FIG.G



- 11 Attach the connectors from the PCFC to the TPS and stock wiring harness as shown in Figure G.
- 12 Reinstall the fuel tank and bodywork.
- 13 Reinstall the passenger seat and the main seat.