Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

> 2191 Mendenhall Dr. Suite 105 North Las Vegas, NV 89031 TEL: 702-399-1423 FAX: 702-399-1431 8am-5pm Pacific Time Monday through Friday

> > Website Address http://www.dynojet.com

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.




E1152.001

European Models Only

1990-96 Honda VT1000 Shadow

Stage 1

For mildly tuned machines using the stock airbox, with stock or K&N filter. May also be used with a good aftermarket exhaust system K&N filter #N/A



Parts List 2 Main Jets DJ150 2 Main Jets DJ155 2 Main Jets DJ160 DNO129 2 **Fuel Needles** 2 **Adjusting Washers** DW0001 2 E-Clips DE0001

WARNING

NO SMOKING! NO OPEN FLAME! WHILE INSTALLING YOUR DYNOJET KIT

STAGE ONE INSTRUCTIONS

1. Remove vacuum slide from carbs. Remove stock needles & spacers, noting order of assembly (Fig. A).

2. Install Dynojet needles on groove #4, using all stock spacers (Fig. A). Install the Dynojet washers above the E-clip.

3. Remove stock main jets and replace with Dynojet mains provided. If you are running the stock exhaust use the DJ155 main jets, if you are running an aftermarket header or slip-on with high flowing baffle, use the DJ160 main jets. Be sure that the jets you are changing are the main jets.

4. Locate the fuel mixture screw (Fig. B). Carefully turn mixture screws clockwise until they seat, turn back out 2-1/2 turns.

Place E-clip in groove #4 from the top

