

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
 North Las Vegas, NV 89031
 TEL: 702-399-1423
 FAX: 702-399-1431
 8am-5pm Pacific Time
 Monday through Friday

Website Address
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.



E2165.001

European Models Only

1996-98 Kawasaki 600 Eliminator

Stage 1&3


STAGE 1

For mildly tuned machines using the stock airbox, with stock or K&N filter #N/A

STAGE 3

For mildly tuned machines using a modified stock airbox. K&N filters #RC-1824

Both stages may be used with a good aftermarket exhaust



This graph shows a typical gain with a Dynojet jet kit.

WARNING

**NO SMOKING!
 NO OPEN FLAME!
 WHILE INSTALLING
 YOUR DYNOJET KIT**

Parts List		
4	Main Jets	DJ086
4	Main Jets	DJ090
4	Main Jets	DJ130
4	Main Jets	DJ134
1	Slide Drill	DD #7/64
4	Fuel Needles	DNO308
8	Adjusting Washers	DW0001
4	E-Clips	DE0001

STAGE ONE INSTRUCTIONS

1. Remove the vacuum slide from the carbs. Remove the stock needles & spacers, noting the order of assembly. Use the slide drill (DD #7/64) provided to enlarge slide lift hole (Fig. A).
2. Install the Dynojet needles on groove #4, using all stock spacers (Fig. A). Install the Dynojet washers above the e-clip (2 per needle).
3. Remove the main jet and replace with the Dynojet main jets provided. Use the DJ086 main jets with stock exhaust, or use the DJ090 main jets with free flowing exhaust systems. Be sure that the jets you are changing are the main jets.
4. Locate the fuel mixture screw (Fig. B). Carefully turn mixture screw clockwise until lightly seated, then turn back out 3 turns.

STAGE THREE INSTRUCTIONS

1. Remove the vacuum slide from the carbs. Remove the stock needles & spacers, noting the order of assembly. Use the slide drill (DD #7/64) provided to enlarge slide lift hole (Fig. A).
2. Install the Dynojet needles on groove #4, using all stock spacers (Fig. A). Install the Dynojet washers above the e-clip (2 per needle).
3. Remove the main jet and replace with the Dynojet main jets provided. Use the DJ130 main jets with stock exhaust, or use the DJ134 main jets with free flowing exhaust systems. Be sure that the jets you are changing are the main jets.
4. Locate the fuel mixture screw (Fig. B). Carefully turn mixture screw clockwise until lightly seated, then turn back out 3 turns.

Fig. A




Fig. B

