

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
 North Las Vegas, NV 89031
 TEL: 702-399-1423
 FAX: 702-399-1431
 8am-5pm Pacific Time
 Monday through Friday

Website Address
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.




E4163.001

European Models Only

2001-02 Yamaha YZF600 R6

Stage 1

For mildly tuned machines using the stock airbox, with stock or K&N filter. May also be used with a good aftermarket exhaust system
 K&N filter N/A



This graph shows a typical gain with a Dynojet jet kit.

WARNING

**NO SMOKING!
 NO OPEN FLAME!
 WHILE INSTALLING
 YOUR JET KIT**

Parts List		
2	Main Jets	DJ134
2	Main Jets	DJ136
2	Main Jets	DJ138
2	Main Jets	DJ140
2	Main Jets	DJ142
2	Main Jets	DJ144
2	Main Jets	DJ146
2	Main Jets	DJ148
4	Fuel Needles	DNO308A
4	Shroud	DNJT07
8	Adjusting Washers	DW0001
1	Shroud Tool	DT007
4	E-Clips	DE0001

STAGE ONE INSTRUCTIONS

1. Remove the vacuum slides from the carbs. Remove the stock needles and spacers, noting order of assembly (Fig. A). To remove the needles from the slides, squeeze the two arrows together and pull out (Fig. B).


2. Locate the Dynojet needle shrouds (DNJT07) provided. With cutaway facing up and towards the engine use the shroud tool provided (DT007) to press over the stock needle jet (Fig. E). When the Shroud is installed properly there will be a small gap between the bottom of the Shroud and the carb body.

3. Install the Dynojet needles on groove #4 from the top. Use all stock spacers (Fig. A). Install the small Dynojet washers above the E-clip (2 for each needle). After installing the slides in the carbs be sure to check slide movement manually.

4. Remove the stock main jets and replace with the Dynojet main jets provided. If you are running the stock exhaust install the DJ140 main jets in the two outside cylinders (1&4) and the DJ136 main jets in the inside two cylinders (2&3). If you are running an aftermarket exhaust or slip-on with a high flowing baffle, use the DJ144 main jets in the outside two cylinders (1&4) and the DJ140 main jets in the inside two cylinders (2&3). Be sure that the jet you are changing is the main jet.

5. Locate the fuel mixture screw (Fig. C). Carefully turn mixture screws clockwise until lightly seated, then back out 1 3/4 turns.

DYNOJET
E4163.001



Place E-clip
in groove #4
from the top

Fig. C







Fig. B

Squeeze Here



Mixture Screw

Fig. E



Shroud Tool
DT001

Shroud
DNJT07