

[POWER COMMANDER V]

2004-2005 Suzuki GSXR600

Installation Instructions



PARTS LIST

- 1 Power Commander
- 1 USB Cable
- 1 Installation Guide
- 2 Power Commander Decals
- 2 Dynojet Decals
- 2 Velcro strips
- 1 Alcohol swab

**THE IGNITION MUST BE TURNED
OFF BEFORE INSTALLATION!**


THE LATEST POWER COMMANDER
SOFTWARE AND MAP FILES CAN BE
DOWNLOADED FROM OUR WEB SITE AT:
www.powercommander.com

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION

Dynojet

2191 Mendenhall Drive North Las Vegas, NV 89081 (800) 992-4993 www.powercommander.com

POWER COMMANDER V INPUT ACCESSORY GUIDE




EXPANSION PORTS 1 & 2

Optional Accessories such as
POD-300 unit or Auto-tune kit.

Wire connections:

To input wires into the PCV first remove the rubber plug on the backside of the unit and loosen the screw for the corresponding input. Using a 22-24 gauge wire strip about 10mm from its end. Push the wire into the hole of the PCV until it stops and then tighten the screw. Make sure to reinstall the rubber plug.

NOTE: If you tin the wires with solder it will make inserting them easier.



ACCESSORY INPUTS

Map -

(Input 1 or 2) The PCV has the ability to hold 2 different base maps. You can switch on the fly between these two base maps when you hook up a switch to the MAP inputs. You can use any open/close type switch. The polarity of the wires is not important. When using the Autotune kit one position will hold a base map and the other position will let you activate the learning mode. When the switch is "CLOSED" Autotune will be activated. (Set to Switch Input #1 by default.)

Shifter-

(Input 1 or 2) These inputs are for use with the Dynojet quickshifter. Insert the wires from the Dynojet quickshifter into the SHIFTER inputs. The polarity of the wires is not important. (Set to Switch Input #2 by default.)

Speed-




If your application has a speed sensor then you can tap into the signal side of the sensor and run a wire into this input. This will allow you to calculate gear position in the Control Center Software. Once gear position is setup you can alter your map based on gear position and setup gear dependent kill times when using a quickshifter.

Analog-

This input is for a 0-5v signal such as engine temp, boost, etc. Once this input is established you can alter your fuel curve based on this input in the control center software.

Crank-

Do **NOT** connect anything to this port unless instructed to do so by Dynojet. It is used to transfer crank trigger data from one module to another.



- 1 Remove the main seat and the passenger seat or solo cover.
- 2 Prop the fuel tank up using the prop rod in the tail section.
- 3 Lay the PCV in the tail section.
- 4 Route the wiring harness from the PCV under the tail section and go towards the engine down the left hand side of the bike.
Be sure to route the harness under the fuel tank bracket.
- 5 Attach the ground wire from the PCV to the negative side of the battery (Fig. A).

- 6 Unplug the stock wiring harness from each of the fuel injectors (Fig. B).

- 7 Plug the connectors from the PCV in-line of the stock fuel injectors and the stock wiring harness (Fig.C).


The pair of PCV wiring harness leads with ORANGE colored wire go in-line of the cylinder #1 (left-most) fuel injector.

The pair of PCV wiring harness leads with YELLOW colored wire go in-line of the cylinder #2 fuel injector.

The pair of PCV wiring harness leads with GREEN colored wire go in-line of the cylinder #3 fuel injector.

The pair of PCV wiring harness leads with BLUE colored wire go in-line of the cylinder #4 (right-most) fuel injector.

FIG.D




- 8 Locate the Throttle Position Sensor connector on the far right hand side of the throttle bodies (Fig. D).

This connector has a PINK/BLACK, RED, and BLACK/BROWN wires.

- 9 Unplug the TPS connector.

FIG.E



- 10 Plug the 3 pin connectors from the PCV in-line of the stock TPS and wiring harness (Fig. E).

- 11 Install the PCV module in the tail section.

The module can be installed as shown in Figure. F or to the inner fender. Use the supplied Velcro to secure the module. Clean the surface with the supplied alcohol swab prior to applying the Velcro.

- 12 Lower the fuel tank back into position, making sure none of the wires or the fuel line get pinched or damaged.

FIG.F



Optional Inputs:

Speed input location - PINK wire of sensor on sprocket cover.

Temperature input location - GREEN connector on back of cylinder. Use the BLACK/BLUE wire.

12v for Autotune - BROWN wire of tail light connector.