

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
 North Las Vegas, NV 89031
 TEL: 702-399-1423
 FAX: 702-399-1431
 8am-5pm Pacific Time
 Monday through Friday

Website Address
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.



E4106.003

European Models Only

1981-82 Yamaha XJ550

Stage 1&3


STAGE 1

For mildly tuned machines using the stock airbox, with stock or K&N filter #YA-1600

STAGE 3

For mildly tuned machines using individual filters or velocity stacks. K&N filters #RC-2372

Both stages may also be used with a good aftermarket exhaust.



This graph shows a typical gain with a Dynojet jet kit.

WARNING

**NO SMOKING!
 NO OPEN FLAME!
 WHILE INSTALLING
 YOUR DYNOJET KIT**

Parts List		
4	Main Jets	DJ140
4	Main Jets	DJ144
1	Slide Drill	DD #40
4	Fuel Needles	DNO466
4	Adjusting Washers	DW0001
4	E-Clips	DE0001

STAGE ONE INSTRUCTIONS

1. Remove the vacuum slide from the carbs. Remove the stock needles & spacers, noting the order of assembly. Use the slide drill (DD #40) provided, to enlarge slide lift holes (Fig. A).
2. Install the Dynojet needles on groove #2, using all stock spacers (Fig. A). Install the Dynojet washers above the e-clip.
3. Remove the main jet and replace with the Dynojet main jets provided. Use the DJ144 main jets with stock exhaust, or use the DJ140 main jets with aftermarket exhaust. Be sure that the jets you are changing are the main jets.
4. Locate the fuel mixture screw (Fig. B), Carefully turn mixture screw clockwise until seated, then back out 3 turns.

STAGE THREE INSTRUCTIONS

1. Remove the vacuum slide from the carbs. Remove the stock needles & spacers, noting the order of assembly. Use the slide drill (DD #40) provided, to enlarge slide lift holes (Fig. A).
2. Install the Dynojet needles on groove #2, using all stock spacers (Fig. A). Install the Dynojet washers above the e-clip.
3. Remove the main jet and replace with the Dynojet main jets provided. Use the DJ144 main jets with stock exhaust, or use the DJ140 main jets with aftermarket exhaust. Be sure that the jets you are changing are the main jets.
4. Locate the fuel mixture screw (Fig. B), Carefully turn mixture screw clockwise until seated, then back out 3 turns.

Notes: Flooding at low speeds can be caused by too high of a float level or too rich of a setting on the fuel mixture screws. If this occurs, try removing the floats and cleaning on top of the floats to remove any dirt that may be lodged there.




Fig. A




Fig. B

