

[POWER] [COMMANDER III]

CERTIFIED **USB**

2008 Triumph Street Triple Installation Instructions


Parts List

- 1 Power Commander
- 1 USB Cable
- 1 CD-ROM
- 1 Installation Guide
- 1 Power Adapter
- 2 Power Commander Decals
- 2 Dynojet Decals
- 2 Velcro® Strip
- 1 O2 eliminator
- 1 Alcohol Swab

You can also download the Power Commander software and latest maps from our web site at:

www.powercommander.com

Button Adjustment Display



Faceplate Buttons


Expansion Port

USB Port




PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION

Fig. A



- 1 Remove the seat.
- 2 Remove the fuel tank.
- 3 Mount the PCIII to the back side of the battery using the supplied velcro. Make sure to clean both surfaces with the alcohol swab before attaching unit.
- 4 Route the PCIII harness down the left hand side of the bike.

Fig. B



- 5 Unplug the stock wiring harness from each injector (Fig. B).
Squeeze each side of the injector to remove.


Fig. C



- 6 Plug the PCIII harness in-line of the injectors and stock wiring harness (Fig. C).


PCIII harness:

- ORANGE - cylinder #3
- YELLOW - cylinder #2
- GREEN - cylinder #1




- 7 Locate the stock Throttle Position Sensor connector (Fig D). Unplug this connection.

Note: This is a 3 pin black connector located to the right of the #3 injector.




- 8 Plug the connectors from the PCIII in-line of the stock wiring harness and TPS connector (Fig. E).



- 9 Attach the ground wire from the PCIII to the negative side of the battery (Fig. F).

Fig. G



- 10 Unplug the O2 sensor from the main wiring harness (Fig. G). This is a 4 pin black connector located near the clutch cover.

This connection can also be seen in Figure E.

- 13 Plug the O2 eliminator into the stock wiring harness. The connector from the O2 sensor does NOT have to be plugged into anything.
- 14 Bolt the fuel tank back into position.
- 15 Reinstall the seat.

Note: The O2 eliminator allows you to get the full potential out of the bike and the Power Commander.