Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
North Las Vegas, NV 89031
TEL: 702-399-1423
FAX: 702-399-1431
8am-5pm Pacific Time
Monday through Friday

Website Address http://www.dynojet.com


The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.

DYNOJETUK.

E5121.001

European Models Only 2005-2006 Triumph Bonneville, T100 & Thruxton 900cc Stage 1

For mildly tuned machines using the stock airbox with stock or K&N filter. May also be used with a good aftermarket exhaust system.



This graph shows a typical gain with a Dynojet jet kit.

WARNING

NO SMOKING! NO OPEN FLAME! WHILE INSTALLING YOUR DYNOJET KIT

Parts List		
2	Main Jets	DJ110
2	Main Jets	DJ112
2	Main Jets	DJ114
2	Main Jets	DJ116
2	Main Jets	DJ124
2	Fuel Needles	DNO308A
2	Slide Springs	DSP027
2	E-clips	DE0001
4	Adjusting Washers	DW0001
1	Mixture Screw Tool	DT008

STAGE ONE INSTRUCTIONS

E5121.001

- 1. Remove the vacuum slides from the carbs. Remove the stock needles & spacers, noting the order of assembly.
- 2. Install the Dynojet needles on groove #4 from the top, using all stock spacers (Fig.A). Install the Dynojet washers above the E-clip (2 per needle).
- 3. Install the dynojet slide springs(DSP027), in-place of the stock slide springs.
- 4. Remove the main jets and replace with the Dynojet main jets provided. Use the DJ110 main jets with stock exhaust. Use the DJ114 main jets with aftermarket header or slip-on with high flowing baffles. If you remove the intake snorkle from the airbox use the DJ124 main jet.
- 5. Locate the fuel mixture screw (Fig. B). Using the tool provided (DT008), carefully turn the mixture screws clockwise until lightly seated, then back out 3 turns.

